



BD ProbeTec™ ET Wet Swab* Specimen Collection and Transport

- Amplified DNA probe test for chlamydia
- Amplified DNA probe tests for chlamydia and gonorrhea

Female Endocervical Swab




1. Remove excess mucus with cleaning swab and discard.




2. Insert the Female Endocervical Swab into the cervical canal and rotate for 15 to 30 seconds.

Male Urethral Swab




1. Insert the Male Urethral Swab 2 to 4 cm into the urethra.




2. Rotate for 3 to 5 seconds.


Specimen Transport




3. Place swab in tube.



4. Break shaft at score line.



5. Screw cap firmly onto tube.



6. Label tube with patient info and date/time collected.

Store and transport at 2 – 27°C for up to 4 – 6 days.



BD Diagnostic Systems
7 Loveton Circle
Sparks, MD 21152-0999
800.638.8663
www.bd.com/clinical

* 220142—BD ProbeTec™ ET *Chlamydia trachomatis/Neisseria gonorrhoeae* (CT/GC) Amplified DNA Assay Collection Kit for Endocervical Specimens
220143—BD ProbeTec™ ET *Chlamydia trachomatis/Neisseria gonorrhoeae* (CT/GC) Amplified DNA Assay Collection Kit for Male Urethral Specimens

BD, BD Logo and ProbeTec are trademarks of Becton, Dickinson and Company. ©2003 BD.
0-2625 May 2003 Printed in USA